

RACEWARE FASTENER APPLICATIONS

	Head Stud	Main Stud	Con Rod	NOTES
<u>Head Stud Kits Continued</u>				
<u>Porsche</u>				
986/996/997 Non-Direct Injection	RWE-1061			NON-Turbo
996 / 997 Twin Turbo	RWE-1055			T.T. only
911/930/964/993 '78 onward	RWE-1022	Studs Only	RWE-4004	9mm Rod Bolt
911/930 thru 1977	RWE-1022	Studs Only	RWE-4003	10mm Rod Bt
Billet, CNC, Head Washers to '77				RWE-6001
Billet, CNC, Head Washers '78 on				RWE-6002
Forged 12 Point Head Nuts - all				RWE-5001
944/944 Turbo thru 1989	RWE-1011	RWE-2009	RWE-4007	Call on '90/'91
968	RWE-1037	RWE-2010	RWE-4007	968 Only
944 16-valve only	RWE-1012	RWE-2009	RWE-4007	16-V Only
3.0L 944 Turbo Conversion	RWE-1047	RWE-2010	RWE-4007	3.0L Conversion
Early 928 2-valve up to 1988	RWE-1014		RWE-4010	Up to 1988
914-4 Std. Length Studs	RWE-1024			10mm thread
914-4 1/2" Long Studs	RWE-1019			10mm threads
914-4 Case Thru-Stud Kit - All				RWE-7001
356 Head Stud Set - (16) Studs	RWE-1027			Studs Only