

Special Tools, Thread Taps & Case Inserts

Application	Part Number	Comment
Timesert TOOL KIT to install RWE-9005K / RWE-9015K Inserts	RWE-9000	Includes Drill, Tap and Installation Tool
Timesert Insert Kits for Type-1 VW case, RWE-1019 and RWE-1019 HSKs. Qty. (16) pcs.	RWE-9005K	Quantity of (16) Timeserts
Timesert Insert TOOL only, for RWE-9005K and RWE9015K	RWE-9005T	Timesert Installation Tool
RACEWARE Stud Installation and removal Tool - fits the following RACEWARE Head Studs - RWE-1001, RWE-1002, etc.	RWE-9010	Fits all RACEWARE HSKs with a top 7/16-20 SAE fine thread
Stud Installation and Removal Tool for RACEWARE Porsche 944/944 Turbo, 928 and 968 Head Studs	RWE-9020	Fits M12 x 1.25mm only HSKs for the Porsche 944, 944 Turbo 928 and 968
Stud Installation and Removal Tool For BMW RWE-1025, RWE-1030, etc.	RWE-1030	Fits 3/8-24 threads only
Porsche 911/930/964/993 Engine Case Timesert Kit - Qty. (24) pcs. (Mandatory on Magnesium Cases)	RWE-9015	(24) Timeserts only for the Porsche 911/930/964/993 (Must use on MAG cases)
M11 x 1.50mm Thread Tap to clean bolt holes	RWE-9200	Fits many VW/Audi Head Bolt Threads
M12 x 1.75mm Thread Tap	RWE-9210	Fits Some Diesel VW/Audi Head Bolt Threads
M12 x 1.50mm Thread Tap	RWE-9220	Fits Porsche 928, 944, 944T, 968 Head Bolt Block Threads
3/8" 12 Point Socket- 3/8" drive	RWE-9300	Fits RWE-1004, RWE-4001
7/16" 12 Point Socket - 3/8" drive	RWE-9310	Fits RWE-1003, RWE-4004
1/2" 12 Point Socket - 3/8" drive - thinwall	RWE-9320	Fits RWE-1001, RWE-1002
9/16" 12 Point Socket - 1/2" drive	RWE-9330	Fits RWE-1011, RWE-1012 RWE-1014, RWE-1037
Ultra Precision 3/8" drive, 0-600 inch/lb. Beam Style Torque Wrench with Memory	RWE-9400 SALE PRICING ***	Guaranteed 2% Accuracy Full Scale
Ultra Precision 1/2" Drive, 0-100 Ft/Lbs. Beam Style Torque Wrench with Memory	RWE-9450 SALE PRICING ***	Guaranteed 2% Accurate Full Scale